

V-715 Zoom channel list

14CH	25CH	42CH	Function	DMX value	Description
1	1	1	Strobe	0 -19	Strobe OFF
				20 -24	Strobe ON
				25 -64	Strobe Fast-Slow
				65 -69	Strobe ON
				70 -84	Slow input Strobe Fast-Slow
				85 -89	Strobe ON
				90 -104	Slow output Strobe Fast-Slow
				105-109	Strobe ON
				110-124	Random Strobe Fast-Slow
				125-129	Strobe ON
				130-144	Random Slow input Strobe Fast-Slow
				145-149	Strobe ON
				150-164	Random Slow output Strobe Fast-Slow
				165-169	Strobe ON
				170-184	Pulse Strobe Fast-Slow
				185-189	Strobe ON
				190-204	Random Pulse Strobe Fast-Slow
				205-209	Strobe ON
210-224	Strobe Fast-Slow				
225-229	Strobe ON				
230-244	Exposure Strobe Fast-Slow				
245-255	Strobe ON				
2	2	2	Dimmer	0 -255	Linear Dimmer Dark-Bright
3	3	3	Focus	0 -255	Linear Focus
4	4	4	Pan Rotation	0 -255	0~540 degree
5	5	5	Pan Fine	0 -255	Pan Fine
6	6	6	Tilt Rotation	0 -255	0~270 degree
7	7	7	Tilt Fine	0 -255	Tilt Fine
8	8	8	Function set	0 -9	No function
				10 -14	Whole light Reset
				15 -39	No function
				40 -44	XY Normal mode
				45 -49	XY Fast mode
				50 -54	XY Slow mode
				55-255	No function

9	9	9	Color wheel	0 -9	No function
				10 -14	Red
				15 -19	Green
				20 -24	Blue
				25 -29	White
				30 -34	2300
				35 -39	2500
				40 -44	2700
				45 -49	3000
				50 -54	3200
				55 -59	3300
				60 -64	3700
				65 -69	4300
				70 -74	4500
				75 -79	4600
				80 -84	5000
				85 -89	5500
				90 -94	5600
				95 -99	6500
				100-104	Light yellow
				105-109	Apple Green
				110-114	Pink
				115-119	Orange
				120-124	Light Orange
				125-129	UV
130-134	No function				
135-174	clockwise				
175-179	Pause				
180-219	Anti -clockwise, speed u				
220-224	No function				
225-255	Random Color , speed down				
10	10	10	Red beam	0-255	Red Dimmer Dark-Bright
11	11	11	Green beam	0-255	Green Dimmer Dark-Bright
12	12	12	Blue beam	0-255	blue dark - bright
13	13	13	White beam	0-255	white dark- bright
14	14	14	Color slow change	0 -7	No function
				8 -39	Red to Yellow
				40 -71	Yellow to Green
				72 -103	Green to Cyan

				104-135	Cyan to Blue
				136-167	Blue to Magenta
				168-199	Magenta to Red
				200-231	Red to White
				232-255	Color change slow - fast
	15		LED gobo	0 -4	No function
				5 -9	Gobo 1
				10 -14	Gobo 2
				15 -19	Gobo 3
				20 -24	Gobo 4
			
				185 -189	Gobo 37
				190 -194	Gobo 38
				195 -199	Gobo 39
				200 -204	Gobo 40
				205 -224	Gobo clockwise run from fast to slow
				225 -234	Stop
				235 -255	Gobo anticlockwise run from slow to fast
	16		Built-in effects	0 -4	No function
				5-19	LED built-in effect1
				20-39	LED built-in effect2
				40 -59	LED built-in effect3
				35 -44	LED built-in effect4
			
				200-219	LED built-in effect10
				220-255	Switch Auto. after 1 minute
	17		Effect speed	0 -255	LED built-in effect speed Slow-Fast
	18		Effect slow input	0 -255	LED built-in effects Gradient Overlay
	19		Effect red	0 -255	Red Dimmer Dark-Bright
	20		Effect green	0 -255	Green Dimmer Dark-Bright
	21		Effect blue	0 -255	Blue Dimmer Dark-Bright
	22		Effect white	0 -255	White Dimmer Dark-Bright
	23		Effect Dimmer	0 -255	Dimmer Dark-Bright
	24		Effect backlight	0 -255	Dimmer Dark-Bright
	25		Reserve	0 -255	No functon
		15	R1Dimmer	0 -255	R1Dimmer Dark-Bright

		16	G1Dimmer	0 -255	G1Dimmer Dark-Bright
		17	B1Dimmer	0 -255	B1Dimmer Dark-Bright
		18	W1Dimmer	0 -255	W1Dimmer Dark-Bright
		
		39	R7Dimmer	0 -255	R7Dimmer Dark-Bright
		40	G7Dimmer	0 -255	G7Dimmer Dark-Bright
		41	B7Dimmer	0 -255	B7Dimmer Dark-Bright
		42	W7Dimmer	0 -255	W7Dimmer Dark-Bright