

## PRO LIFTING TOWERS

Installation & User Manual



**LW 415R**


**LW 425R**

**LW 461R**

**LW 476R**

**EN**



**LW 415 R****LW 425 R****LW 461 R****LW 476 R**


<b>INTRODUCTION</b>	1
<b>FEATURES</b>	2
<b>SPECIFICATIONS</b>	3
<b>FASTENER SYSTEM (explanation)</b>	3
<b>SAFETY RULES</b>	5
<b>INSTALLING THE LIFTING TOWER</b>	9
<b>PLACING THE LOAD</b>	10
<b>WINCH OPERATION (Special care)</b>	13
<b>LIFTING PROCESS</b>	14
<b>DESCENT/FOLDING PROCESS</b>	16
<b>CONFORMITY DECLARATION</b>	19
<b>BGV C1, EXPLANATION &amp; TEST</b>	20

# INTRODUCTION

**400 series** has been a big change in the way of work when professionals needs to lift heavy loads. The big success resides in the loading at the ground level avoiding unnecessary efforts that before can not be solved easily.

As usual in **WORK®** products, all the components have been oversized with the goal of achieving a superior security:

- High resistance aluminium profiles.
- Powerful autoblocking bolts.
- Steel made pulleys.
- Autoblocking certified winches.
- 2 iron braces placed in the back side to reinforce.
- Bubble level indicator vial
- High resistance legs.
- Strong cable of security made of steel under the DIN normative



### LW 461R / LW 476R

The transport of both tower models, can be converted in a very simple operation due to the wheels placed on the both towers base and two additional wheels with a big size and folding to the body of the tower which always solve the uncomfortable operation of managing the tower loading up or getting of from a lorry or track.


**LW476 & 461** towers have the best features to get lifted the most complicated loads. Their materials, made of steel, assure to the user the security and reliability without renouncing to the comfort and easy use.

## IMPORTANT


ALL DRAWINGS IN THIS USER MANUAL ARE BASED ON LW 476R LIFTING TOWER. THE MODELS LW 461R, LW 415R & LW 425R INCORPORATE THE SAME OPERATION METHOD.

# FEATURES


These towers have a light inclination (2°) over the vertical axis in order to displace the gravity centre to the opposite side of the load, getting a better balance with the coupled load.




### For the transport, LW 461R and LW 476R incorporate a folded wheel system



With this system, is possible to make more easy the transport process in a lorry or track, the wheel allow to lean the tower over the lorry base and to displace it So the winch does not suffer scratches or hits.



The transverse pieces placed between the base and mast provide an extra firmness Additional wheels for an easy load up or get down process from a lorry or track.



Fork carrier profile in order to support the elevated load.


## SPECIFICATIONS

	MAX LOAD (KG)	MIN LOAD (KG)	DISPLAYED TOWER		FOLDED TOWER		WEIGHT (KG)
			HEIGHT (M)	BASE (M)	HEIGHT (M)	BASE (M)	
LW 415 R	170	30	5,0	2,20 x 1,70	1,89	0,48 x 0,50	82
LW 425 R	150	30	6,5	2,20 x 1,70	1,89	0,48 x 0,50	90
LW 461 R	250	30	6,1	2,00 x 1,85	1,90	0,70 x 0,60	140
LW 476 R	220	30	7,6	2,00 x 1,85	1,90	0,70 x 0,60	163

	CABLE						WINCH	
	COMPOS. (GALVANIZED)	Ø (mm)	RESIST. (N / mm2)	LOAD (KN - KP)	WEIGHT/Mt (KG/M)	ROLL.	Ø BOBBING (mm.)	REDUCT. RANGE
LW 415 R	6 x 19+1	5	1770	19.6 - 1990	0,077	CROSSED TO RIGHT	48	3.75 : 1
LW 425 R		5						
LW 461 R		6						
LW 476 R		6						

Standards and Regulations applied on winches incorporated on each lifting tower.


MODEL	STANDARDS AND REGULATIONS
LW 415 R	DIN 15020 / VGB 1 / VGB 8
LW 425 R	DIN 15020 / VGB 1 / VGB 8
LW 461 R	DIN 15020 / VGB 1 / VGB 8
LW 476 R	DIN 15020 / VGB 1 / VGB 8




### FASTENER SYSTEM

This system uses a profiles specially designed in order to bear heavy loads. The wide of these profiles and the thickness of their walls ensures a big firmness of the set. These profiles incorporate a rail with a serie of fixation holes where the security bolt are located.

These holes have the sufficient size in order the bolts could be introduced quickly, providing the folding speed of the tower.




The security bolts have been oversized as much as piston diameter as main fixation piece. The block/unblock system through a light pull and turning it allows to make these operations easily and above all with security.



The pulley system (upper and lower on each profile) entrusts to transmit the generated strain in the winch and to elevate the profiles, for this reason, these pulleys disposes of an appropriate design in order to handle the cable, enclosing the whole system in a compact set.


## SPECIFICATIONS



### FASTENER SYSTEM (explanation)

The fastener system operates in following way:  
We turn clockwise the winch that tighten the cable and thanks to the pulley system, the more outer profile is elevated.  
This situation is not 100% assured. The load could deploy an intermediate section but the lifting process will restore the normal unfolding.

**ALL SECURITY BOLTS MUST BE IN BLOCK POSITION,** so the elevation of the profile cause that the spring pin of the bolt retracts, which triggers when a hole of the profile is located in parallell with it, blocking the tower in that position.



In this point, there is a strain in the cable in order to keep unfolded the pulley system, but all load is supported by the security bolts, releasing the winch and give up using it.

We continue elevating the tower up to the security bolt locates in the las hole of the elevated profile. In that moment, the next profile is elevated identically up to total tower folding.



For the descent, we must to unblock the lower security bolt and turn the winch on inverse sense, the load bring down the profile up to the stand position, in that moment we must to block the bolt for the transport use and we must unblock the new security bolt from the descended profile.

We proceed in the same way, with all profiles up to the total tower unfolding.



## SAFETY RULES




Do not elevate the tower without using the stabilize legs.



Place the tower over a flat and stable surface. Do not install it in a place where the use over the stabilize leg would not be enough to reach a perfect balance.



The two largest legs must be placed in the frontal tower side and the shortest ones at both winch sides.



Act individually over the stabilize leg up to the wheels lose contact with the ground and ensuring a perfect balance of the tower. This balance will be showed in the vial.



Do not move away the stabilizer legs after the load is elevated.


## SAFETY RULES



Do not move the tower after the load is elevated



Do not lean elements (like stairs, platforms, scaffoldings, etc.) over the tower which can make pressure over it and to destabilize



For outdoor installations ensure the tower with security ties to ground. NEVER fix them to surfaces with oscillations like structures, etc.




Do not use the tower like support for banners or decorates support. With heavy wind, these elements could act as "sail" and to knock over the tower.



Do not use the tower in heavy wind conditions. Take into account that if the exposed height and surface is maximum, the tower stability is reduced.


## SAFETY RULES



The load must be firmly placed over the support the nearest possible gravity center of the tower, in order to facilitate its balance.



Do not overload the tower beyond the max. weight recommended in the manufacturer specifications.




In the moment you elevate the tower, check that it does not take contact with elements or objects which with the tower could hit or come off.

Be aware specially with the electrical conductions, due to the towers are not electrically isolated, it can represent a serious electric shock danger.




Do not stay down to the tower after the tower elevation nor elevation or folding process.



This tower is not designed to elevate persons. Do not use it for a different purpose that it has been designed


## SAFETY RULES




Keep the hands and fingers moved away to mobiles elements of the towers like profile unions.



Do not lubricate the brake system of the winch, the mechanism could lose efficiency.



Do not catch the cable during the elevation or folding process.



Avoid the non-desired tower manipulation by non-qualified people.



Check periodically the good winch conditions of the and cable security. In order to guarantee the security cable integrity, consult the section about the winch operation.



**NOT TAKE INTO CONSIDERATION THESE RULES COULD CAUSE THE KNOCK OVER OF THE TOWER OR ITS LOAD, PROVOCATING DAMAGES IN PEOPLE AND PROPERTIES**

## INSTALLING THE LIFTING TOWER


Place the tower over a flat and stable surface to install the tower, discarding its use over rolling platforms or surfaces which would be able to bear as much its own weight as coupled load.

The installation area must be free of debris, stone, etc. that reduce the firmness of the tower at ground.

Moreover the tower must not be placed near elements which can obstruct the vertical folding process like balconies, cornices, etc.

Be aware specially with the proximity of electric cables which the tower could take or crimp them. Consider that the tower is not electrically isolated, so, it can be loaded with electricity and to constitute a serious electric shock risk.

The tower disposes of two sets of legs with different length in order to settle the tower. Remove them for the transport support in order to insert them.



When you place them, consider that the 2 longest legs must be placed in the frontal side of the tower and the shorter ones in both sides of the winch.



**Longest legs placed in the front side of the tower.**


## INSTALLING THE LIFTING TOWER



For better security during the transport, these towers incorporate a profile fixation system that impedes the movement of the profiles. You must release it acting over the piece with extension spring and the piece located in the fixation hole.


**(Only for LW 461R/LW 476R models)**

**NOTE: REMEMBER TO RELEASE THIS DEVICE BEFORE ELEVATING THE TOWER AND FIX IT WHEN THE FOLDED PROCESS IS FINISHED**



In order to insert the legs, use corresponding pin bolt and insert the leg to correct position triggering the bolt. To ensure the set stability.

Rotate the crank of the stabilizer placed on each leg up to the wheels located in the base do not touch the ground. During this process, control the vial in order to act individually over each stabilizer up to obtain a perfect balance.



### PLACING THE LOAD


Once the tower is fixed and balanced over the ground, you can proceed to locate the load over the incorporated support.

**NOTE: THE HOLDER DESIGN ALLOWS THE LOAD ELEVATION FROM 30 CM OF THE GROUND, PROVIDING ITS HANDLING.**

For this purpose, remove the external bolt located on each arm in order to make the extraction. This support must be placed in horizontal position and the pin bolt must be fixed again.



## PLACING THE LOAD



Support in stand position for transport. Extract the pin bolts and place it in horizontal position in order to locate the load.

**NOTE: IN ORDER TO ELEVATE TRUSS SYSTEMS, THERE IS AN OPTIONAL DEVICE IN "U" SHAPE WHICH IS FIXED THROUGH THE HOLES OF THE SUPPORT AND PROVIDED AN APPROPRIATE FIXATION FOR THIS TYPE OF LOAD.**




Place the load over the support, taking into account the security recommendations indicated in the HANDLING PRECAUTIONS section, like this:

- To assure stability and balance of the lifting tower.
- To place the load the nearest possible to the gravity center of the tower in order to avoid the "lever effect".
- Do not overpass the weight recommended in the manufacturer specifications.
- To assure and fix the load in order to avoid load movements.


**NOTE: In order to make easy the load descent process and tower folded, the minimum load coupled on the tower must not be smallest than 30 Kg.**

## PLACING THE LOAD

Before elevating the tower, you must unblock the security bolt located in the wheel transport system, so the wheel pass to stand position and the elevation process can start.



**HINT: IT IS POSSIBLE TO OBTAIN AN EXTRA HEIGHT, FLIPPING THE SUPPORT. FOR THIS OPERATION, YOU MUST RETIRE THE CENTRAL SCREW AND TO CHANGE THE POSITION ON THE SUPPORT PIECE.**




**NOTE: MIND IF THE LESS ADDITIONAL HEIGHT OBTAINED WITH THIS WAY, MAKE UP FOR THE INCREASE OF THE LOAD FALL RISK. THIS OPERATION MUST BE MAKE BY QUALIFIED PERSONNEL.**

## WINCH OPERATION ( SPECIAL CARE)

During the tower elevation process, pay attention to the cable rolling. This cable must be coiled in parallel turns around the winch cylinder NEVER MUST BE PRODUCED CABLE CROSSES IN DIFFERENT DIRECTIONS.



In this way, that cable can be dangerous or got worn, causing, at the end, the break of the cable.

If any spiral is rolled in this way, turn the winch in opposite sense up to release of wrong turn. Then, proceed to coil again in an appropriated way




## LIFTING PROCESS


**NOTE: BEFORE ELEVATING THE TOWER, CHECK THAT ALL BOLTS ARE IN BLOCK POSITION.**




Blocked bolt (CORRECT)




Unblocked bolt (INCORRECT)



Turn the winch smoothly in clockwise direction, during this process, the load will start to elevate with the support. Be careful in all moment with oscillations due to a deficient load. Continue with this process up to the support reach the prefixed height.




Load located in the most elevated point  
(Before to folding it)




From this moment, the zip system in the profiles start to operate. Each profile is designed in order to carry out a double objective: To house the security system from the previous profile and to arrange the appropriate insertions in order the bolt of the next profile accommodate during the elevation process.

## LIFTING PROCESS




1. Now you can turn the winch in clockwise direction, the first profile starts to elevate and the security bolt of the next profile moves slightly to the outside when a solid part of the profile passes in front of it.



2. You can continue elevating the profile up to fully folded, that coincide with the block of the bolt over the last fixation hole.

This situation is not 100% assured. The load could deploy an intermediate section but the lifting process will restore the normal unfolding.



3. In this detail, you can appreciate the holes that allow to block the security bolts, its shape allows a better balanced of the coupled load.
4. Once fully folded the first profile, the friction between profiles occasionated by the load, do that the next profiles elevate by the same way. When the trigger is shot over the last fixation hole in the profile, the last profile is elevated.




This is the aspect of the LW 461 R with its 4 profiles folded at its max. Height. In this way it is able to elevate loads up to 6.5 meters.

## DESCENT/FOLDING PROCESS


For the descent, we must unblock the lower security bolt and turn the winch on inverse sense, the load bring down the profile up to the stand position. In that moment, we must block the bolt for the transport use and we must unblock the new security bolt from the descended profile.

We proceed at the same way with all profiles up to the total tower unfolding.



Finally, we must descend the support system up to the position more lower and removing the load. Now, we must dismantle the fork carrier set, releasing the pin and inserting the two forks in its transport position (vertically).

Insert the two fork vertically and block with the two pins.



Ensure the profiles placing the fixation bar and ensuring with the pin.

Rotate the crank of the stabilizer placed on each legs up to the wheels located in the base touch the ground.

**This process must be make step by step, that is, several rotations one each crank avoiding the unbalancing of the lifting tower until to complete the process**




Pin bolt for leg insertion



In order to extract the legs, use corresponding pin bolt and extract the leg triggering the bolt.



Place them in the leg transport enclosure, taking into account that the two more longer leg must be placed in the outside.



**NOTE:** When you lift down the lifter, if any sections will not fully go down, stop to rotate the winch because the system will be loosened and it would bring about a sudden descent of this section.

To avoid it, rotate the crank in the opposite sense as if you lift down and insure that the bolt of this section is unblocked, so repeat the lifting down process. In the case the problem persists, look after that the lifter has a minimum load to ease the descent of sections.

**NOTE:** In systems or intallations where 2 lifters are assembled, the descent (and lifting) process should be make simultaneously in order to avoid an unbalance of heigh in whatever of both sides, and that could cause the swinging of the load and in extreme cases, the fall of the tower.



### INTRODUCTION

New V.1204 blocking system applied to **WT 500 & LW 476 R**, incorporates two security blocking systems.

The first system (**marked as A**) allows to block the profiles to transport or block a profile individually.

The second system (**marked as B**) is an automatic trigger, unblocking it, allowing to deploy or undeploy the profile, blocking it in the prefixed fixation position.

### OPERATION

1. All triggers must be in block position for transport.
2. When the lifter will be placed in position and secured with the legs, block all triggers for automatic system (**marked as B**) and unblock the most external trigger for the first system (**marked as 1**).
3. Using the winch, we will ONLY deploy the first profile. This profile will be blocked in the first prefixed position, if we want to deploy more, act over the winch and the profile will be deployed automatically until the next prefixed position. During deploying process, the automatic system (marked as B) will be blocking/unblocking in the inner holes placed in the profile, becoming in an additional security system.
4. Once reached the desired position of the first profile, **BLOCK** again the trigger of the first system (**marked as 1**).
5. Now, repeat the process with the next trigger of the first system (**marked as 2**), unblocking it to deploy the associated profile.
6. Repeat all process until deploying all profiles.

### UNDEPLOYED

1. Repeat the process in inverse way. Unblock the trigger **marked as 3**, the associated profile will descend until reaching the stand position. In this moment, **BLOCK** the trigger **marked as 3**.
2. Now, proceed in similar way with the next trigger (**marked as 2**)
3. Repeat this process until reaching the stand position of the whole lifter.
4. **CHECK** as all trigger of **system A** are blocked and **BLOCK** all trigger of **system B** to transport the lifter.

## CONFORMITY DECLARATION

The described Truss-Lifts meets all the requirements specified in the Directive 2006/42/EC of the European Parliament and the Council of 17 May 2006 on machinery, and amending Directive 95/16/EC.

Applicant : **EQUIPSON, S.A**  
Address : Avda. El Saler, 14 Pol. Industrial L'Alteró  
46460 SILLA - Valencia (Spain)  
Representative : **EQUIPSON, S.A**  
Address : Avda. El Saler, 14 Pol. Industrial L'Alteró  
46460 SILLA - Valencia (Spain)  
Description : Lifts for Truss Systems

**WORK®** LW 415 R  
**WORK®** LW 425 R  
**WORK®** LW 461 R  
**WORK®** LW 476 R



Juan José Vila  
(Product Manager)  
October 22, 2009

The test report was carried out from the submitted type-samples of a product in conformity with the specification of the respective standards. The certificate holder has the right to fix the CE-mark on the product complying with the inspection samples.

## BGV C1 REGULATION, Explanation

**BGV C1** is a regulation for Staging and Production Facilities for the Entertainment Industry. Lifting and rigging equipment is just part of this standard and cover structures and other technical matters.

Adopting

**BGV C1** is entirely voluntary (except in Germany) but its adoption is generally required by insurance companies and therefore it has effectively become an industry standard.

The application of this standard over lifting towers is vital due to in theatres, stages, etc. are used to move loads over performers and, in some cases, above spectators, representing a potential falling risk.

## BGV C1 REGULATION, Application fields

This standard is orientated in two ways:

By one side, the lifting towers adopt designs and materials in order to achieve a high security degree in magnitudes like load supported, balance, friction resistance, etc.

So a **WORK®** lifting tower **BGV C1** certified ensures the customer that has passed strict test during its design, materials choice or load and effort verifications.

By other side, in order to achieve an optimum operation with these units, is recommended as much a responsible use of the unit, complying basic rules like maximum load accepted or tower balance as maintenance periodic, which must be carried by expert technicians, checking the good state of the steel cable and winch, operation of the safety bolts and folding/unfolding of the entire profile system.

**ANNUAL TEST (passing the fourth year)**

Checked by

Date

Signature

Tested elements and conclusions

**ANNUAL TEST (passing the fourth year)**

Checked by

Date

Signature

Tested elements and conclusions

**ANNUAL TEST (passing the fourth year)**

Checked by

Date

Signature

Tested elements and conclusions

# BGV C1, TESTS & CHECKS

MODEL

SERIAL NUMBER

**INITIAL CHECK (First year)**

Checked by

Date

Signature

Tested elements and conclusions

**FOUR YEARS TEST**

Checked by

Date

Signature

Tested elements and conclusions





[www.worldlifters.com](http://www.worldlifters.com)

EQUIPSON, S.A. Avda. del Saler, 14 - Pol. Ind. L'Alteró (Silla) - 46460 Valencia- Spain- Tel. +34 96 121 63 01 - Fax +34 96 120 02 42 - [equipson@equipson.es](mailto:equipson@equipson.es)/[www.equipson.es](http://www.equipson.es)