



BOTTICELLI 1.250 — 2.500 W Quartz-Halogen Softlight

INSTRUCTION MANUAL








1. INTRODUCTION

Congratulations on your purchase of a BOTTICELLI 1250/2500 W lighting fixture from De Sisti Lighting, our commitment to Total Customer Satisfaction and a consolidated experience in leading the innovation in the manufacturing of lighting products for the professional Entertainment Industry mean you can depend upon the quality of this product. The BOTTICELLI 1250/2500 W is a compact and robust softlight using 2 tungsten-quartz-halogen linear filament lamps having R7s sockets, Length of 189 mm. and max. 2500 kW power each.

2. YOKE AND ACCESSORIES ASSEMBLY





3. SAFETY INSTRUCTIONS

- **Professional use:** This luminaire has been designed for professional use and must be operated by qualified personnel only. **Not for residential use.**
- **⇒** Grounding: WARNING: THIS LUMINAIRE MUST BE GROUNDED
- **□** Electrical connections: IMPORTANT The cores in this mains lead are colored in accordance with the following code:

	Europe	America	
Ground	Green & yellow	Green or green & yellow	
Neutral	Blue	White	
Live	Brown	Black	

In case the colors of the cores do not correspond to the colors of the connection points on your plug, please proceed as follows:

- the green or green and yellow core must be connected to the connection point marked with the letter E or with the symbol (*) or colored in green or in green yellow;
- the blue (or white) core must be connected to the connection point marked with the letter N or colored in black;
- the brown (or black) core must be connected to the connection point marked with the letter L or colored in red.

Working conditions

 Working Position 	Max. Tilting on vertical plane ±90° from straight horizontal			
 Ambient Temperature, t_α 	-20° C ÷ +45° C			
 Minimum distances from 	Тор	Back	Sides	Front
inflammable surfaces	0,4 m.	0,1 m.	0,1 m.	4 m.

The luminaire should never be OPERATED close to inflammable materials. The ones indicated in the above table are the minimum distances recommended. Other requirements for safe use are:

- A. Do not cover the apertures of the luminaire housing. They are essential for correct ventilation. Do not use on the floor. It reduces the ventilation.
- **B.** Use only original accessories and spares from De Sisti Lighting.
- C. Before hanging the luminaire ensure that the suspension point (or the stand) is properly rated to accept the luminaire weight.
- D. In case of pole operated use, fit only a P.O. stirrup from De Sisti Lighting.
- **E.** A suitable secondary safety suspension device (safety cable, chain or equivalent) must be fitted between the suspension point and the eyelet at the front of the body .

WARNING: DO NOT MOUNT THE LUMINAIRE ON A NORMALLY FLAMMABLE SURFACE.



4. INSTALLATION INSTRUCTIONS

Before connecting the luminaire to the electrical mains ensure that:

- A Earth line is present on the power socket.
- B The mains voltage is within the rated range of the luminaire (see technical data on the rating label)
- C The lamp fitted:
 - is among the usable lamps (check with your De Sisti dealer)
 - has the same nominal voltage as the mains supply
 - has a nominal power not higher than maximum power of the luminaire.
- D The front safety shields against the lamp explosion are present and in good condition. They consist wire guard 3x3 mm .

WARNING: SHIELDS, LENSES SAFETY OR DICHROIC GLASSES SHALL BE CHANGED IF THEY HAVE BECOME VISIBLY DAMAGED TO SUCH AN EXTENT THAT THEIR EFFECTIVENESS IS IMPAIRED, FOR EXAMPLE BY CRACKS OR DEEP SCRATCHES. THE LUMINAIRE SHALL ONLY BE USED COMPLETE WITH ITS PROTECTIVE SHIELD.

5. LAMP INSTALLATION AND REPLACEMENT

The following procedure should be adopted:

- A Ensure the luminaire is electrically isolated from the power supply.
- B WAIT LEAST 5 MINUTES FROM SWITCHING OFF to avoid risk of injury from possible lamp explosion. Then open lens door .

WARNING: AFTER THE ABOVE MENTIONED TIME THE LAMP MAY STILL BE VERY HOT, USE PROPER THERMAL PROTECTION (EG. GLOVES).


- C Check that the new lamp is of the correct type (see item 4.C).
- D Replace the lamp taking good note of the following:
 - do not touch the bulb with bare-hands; oil and grease can contaminate the bulb surface and then reduce the performance and the lamp life.
 - The plastic cover which protects the lamp should not be removed until after fitting.
 - Should the bulb become dirty due to hand contact or for any other reason, it can be cleaned with a cloth moistened with alcohol
- E Ensure that the door is securely closed.


WARNING: THE LAMP MUST BE REPLACED IF IT HAS BECOME DAMAGED OR DEFORMED.



6. CARACTERISTICS AND PERFORMANCE DATA

DESCRIPTION	VALUE				
⇒ Power Input	Max. 25	Max. 2500W			
⇒ Power supply	Euro	Europe		America	
	230 V /	0-50	110 V / 0-60		
	H:	Hz		Hz	
Switch on the fixture	M.O.		P.O.		
HAIOTO	2 x TOGGLE 10 A		Europ	Ameri	
			е	са	
			Rotary	2 x	
			25 A	Toggle 10 A	
⇒ Lamp Holder	R7s				
	Spring Type				
⇒ Power Cable	Europe		America		
	3 x 2.5 mm ²		3 x 14 AWG		
			TYPE SO		
			90° C rating		
Protection	Class 1 – it requires ground				
Class	connection				
⇒ Protection	IP 22				
Туре					
⇒ Max. Housing					
Surface	102° C				
Temperature					
Weight of Fixture	M.O.	M.O. USA	P.O.	P.O. USA	
	12 kg	11.7 kg	13 kg	12.8 kg	
⇒ Weight of	24,5 mm		49 mm		
S Weight of Egg-crates	tickness		tickness		
Lgg-cruies	1.31 kg.		2.2	2.26 kg.	
Weight of color frame	0,67 kg.				







7. PERIODIC INSPECTION

- A. The condition of the internal wiring insulation and of the input cable shall be inspected and tested every 500 working hours and at least once a year. This frequency may need to be increased if rough or unknown (eg. rental) treatment is incurred. Replace only with original De Sisti Lighting spare parts. Non-original cables may not withstand the thermal and mechanical conditions of use
- B. The lamp condition must be checked every 100 working hours. For lamp replacement follow the procedure of point 5 and the instruction of the lamp manufacturer .
- C. Check the condition of the safety shield (see chapter 4-D: Installation Instructions) before every use.

8. SAFETY STANDARDS

Europe: The product conforms the Applicable European	·
Directives & Standards	NEC & UL stds.
Dow Voltage Directive: 73/23/EEC (as amended by 93/68/EEC)	
⇒ EMC Directive: 89/336/EEC (as amended by 92/31/EEC & by 93/68/EEC)	
Europen Standards:: EN 60598-2-17, EN 60598-1, EN 55015, EN 61547	