Source Four *mini*



CE User Manual

Revision B

Copyright © 2013 Electronic Theatre Controls, Inc.

All Rights reserved.

Product information and specifications subject to change.

Part Number: 7063M1210 Rev B

Released: 2013-07

Table of Contents

Source Four Mini CE Guidelines1
Introduction
Basic Assembly3
Install Lens Tube4
Adjustments4
Adjusting the yoke position
Shaping the Beam
Colour Frame Holder6
Replacing the Lamp7
Cleaning the Glass Lens8

ETC®, Eos $^{\text{II}}$, Eos Ti $^{\text{II}}$, Gio $^{\text{R}}$, Ion $^{\text{R}}$, Element $^{\text{II}}$, Emphasis $^{\text{R}}$, Expression $^{\text{R}}$, Insight $^{\text{II}}$, Imagine $^{\text{II}}$, Focus $^{\text{II}}$, Express $^{\text{II}}$, Unison $^{\text{R}}$, Obsession $^{\text{R}}$ II, ETCNet2 $^{\text{II}}$, EDMX $^{\text{III}}$, Revolution $^{\text{R}}$ and Sensor+ $^{\text{R}}$ are either registered trademarks or trademarks of Electronic Theatre Controls, Inc. in the United States and other countries.

ETC permits the reproduction of materials in this manual only for non-commercial purposes. All other rights are reserved by ETC.

ETC intends this document, whether printed or electronic, to be provided in its entirety.





Unit 26-28 Victoria Industrial Estate Victoria Road London W3 6UU Tel +44 (0)20 8896 1000 Fax +44 (0)20 8896 2000

We, Electronic Theatre Controls Limited

declare under sole responsibility that the product:

Product name: Source Four Mini luminaire

Product type/model: Source Four Mini Canopy mount, Source Four Mini

Track mount & Source Four Mini Clamp mount.

Versions fitted with tungsten lamp.

Item numbers: One sample of each type

to which this declaration relates is in conformity with the following Standards:

EN 60598-1:2008 Luminaires. General requirements and tests

EN 60598-2-6:1995 Luminaires. Particular requirements. Luminaires with built-in

transformers for filament lamps

EN 60598-2-17:1989 Luminaires. Particular requirements. Specification for luminaires

for stage lighting, television, film and photographic studios

(outside and indoor)

following the provisions of EU LV Directive(s) 2006/95/EC

EN 55015:2006 Limits and methods of measurement of radio disturbance characteristics of electrical lighting and similar equipment

EN 61547:2009 Equipment for general lighting purposes. EMC immunity

EN 61000-3-2:2006 Electromagnetic compatibility (EMC). Limits. Limits for harmonic

current emissions (equipment input current up to and including

16 A per phase) Class C

EN 61000-3-3:2008 Electromagnetic compatibility (EMC). Limits. Limitation of

voltage changes, voltage fluctuations and flicker in public lowvoltage supply systems, for equipment with rated current <= 16 A

per phase and not subject to conditional connection

following the provisions of EU EMC Directive(s) 2004/108/EC

London, United Kingdom (Place of issue)

11th March 2013

(Date of Issue)

Mr Adam Bennette

(Name of authorised person)

(signature of authorised person)

Printed 11 Mar. 13 Decl # 117

\LON-FILE2\Shares\RND\DofC\Master declaration.doc

Page 1 Version # A

Source Four Mini CE Guidelines

Read the entire User Manual before using the equipment.





WARNING: Please note the following safety precautions:


- Do not mount the Source Four Mini CE on or near a flammable surface.
- The Source Four Mini CE is suitable for indoor use only with a maximum ambient temperature: 40°C.
- Maximum exterior surface temperature: 125°C.
- · Relative humidity 90% maximum, non-condensing
- If the external cable is damaged, it shall be replaced by ETC or our service agents.
- Always hang the Source Four Mini CE with the colour frame held securely behind the retaining clip.
- Always replace the lamp if it becomes damaged or thermally deformed.
- Disconnect the unit from power before all cleaning and maintenance.
- Keep the luminaire at least 3cm away from any lit surface. Lighted objects at this distance or greater will not exceed 90°C temperature from projected light.

Introduction

The Source Four Mini has four field-angle choices and comes in a portable version with a yoke mounted transformer, a canopy-mount design with an integral transformer, and a track-mount design with an integral transformer. Surprisingly bright for its size, the Mini offers crystal-clear image projection and a bright, even field.







Canopy

There are three versions of the Source Four Mini. This manual covers common features for all versions. For information on installing the canopy and track-mount variations, see the Source Four Mini Canopy and Track-Mount Kits Installation Guide.



WARNING:

Please note the following safety warnings before use:

Do not mount the luminaire on or near combustible surfaces.

Always hang the luminaire with the colour frame retaining clip in the locked position.



WARNING:

Track Mount Version

To reduce the risk of fire and electric shock, use only with **EUTRAC** track system.



Note:

Dimmable by most forward and reverse phase dimmers. Reverse phase dimmers are recommended for best performance. Forward phase dimming may result in an audible noise and


should be tested before installation.



Note:

The Source Four Mini yoke has a C-clamp hole for an M10 bolt.

Basic Assembly



INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

IMPORTANT SAFETY INSTRUCTIONS

Lighted lamp is HOT!


WARNING - To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION, OR INJURY TO PERSONS:

- 1) Turn off/unplug and allow to cool before replacing lamp.
- 2) Lamp gets HOT quickly! Do not turn power on again before the fixture is reassembled.
- 3) Do not touch hot lens, guard, or enclosure.
- 5) Do not use in proximity to normally flammable materials.
- 6) Use only with a lamp rated at 50W or less.

SAVE THESE INSTRUCTIONS

Install Lens Tube

A lens tube must be installed prior to use of the Source Four Mini. There are four lens tubes available; 19°, 26°, 36°, and 50°.



Step 1: Unscrew the beam focus knob from the loose lens tube.

Step 2: Slide the lens tube into the shutter barrel.


Step 3: Install the beam focus knob.

Adjustments

Adjusting the yoke position

The Source Four Mini provides multi-positioning capabilities within its yoke for overall luminaire angle.

Setting the angle with the yoke




Step 1: Loosen the yoke locking knob. **Do not** remove the knob.

Step 2: Tilt the luminaire to the desired position.

Step 3: Tighten the voke locking knob to secure position.

Locking the rotation in the canopy and track-mount variations



Step 1: Rotate the luminaire into the desired position. Luminaire will be prevented from rotating completely around to protect the wiring.

Step 2: Insert a 1.5mm Allen wrench into the small hole on the yoke lock.

Step 3: Turn wrench to tighten down the yoke lock.

Focusing the beam

Step 1: Loosen the beam focus knob located under the barrel. **Do not** remove the knob.

Step 2: Slide the lens tube forward or backward to achieve the desired beam edge.


Step 3: Once the luminaire is focused, tighten the

beam focus knob.


Shaping the Beam

The beam can be shaped using the four shutters or with a gobo pattern.

The Source Four Mini has four shutters: left, right, top, and bottom. Each shutter can be pulled out or pushed in to create the desired beam shape.



Beam focus knob





Shown at actual size.

Gobo Pattern Projection

The Source Four Mini has a gobo holder slot on the top side of the shutter barrel, in front of the shutter. It accommodates a E-size (37.5mm with a 25.4mm image area) gobo pattern holder.

Use an optional donut in the colour frame holder to enhance pattern projection.

When the slot is not in use, a small sheet metal cover secured with a Phillips screw prevents light leakage.

Step 1: Use a Phillips screwdriver to loosen the

screw on the slot cover. Do not remove the

screw.

Step 2: Slide the cover completely forward to

expose the slot.

Step 3: Insert the gobo holder.

Step 4: Slide the slot cover back toward the shutters until it meets the handle. Leave

enough space to move the handle.

Step 5: Secure the slot cover by tightening the

screw.

Colour Frame Holder

The Source Four Mini comes equipped with a 70mm colour frame, which is a metal frame used to hold colour media (often referred to as gel) in front of the lens. The colour frame holder is equipped with a retaining clip that prevents the colour frame from falling out.



<u>WARNING:</u> Make sure the colour frame is locked in position with the retaining clip.



Note: The colour frame should be inserted open side down.

Step 1: Release the retaining clip by gently

bushing it up.

Step 2: Insert the colour frame.

Step 3: Lock the retaining clip by gently pushing it down.


down.

Additional accessories are available for the Mini that also fit into the colour frame holder. Those

accessories are top hat, short top hat, half hat, short

half hat, and donut. When an accessory is used, the colour frame should be installed in the rear slot of the holder.

Replacing the Lamp



Step 1: Disconnect power to the Source Four Mini before installing the lamp.

Step 2: Loosen the brass lamp housing knob on the back of the lamp housing. The

knob is not captured so it may come loose from the luminaire.

Step 3: Pull the lamp housing away from the luminaire body.

Step 4: Pull on the lamp carefully to remove it from the lamp housing.

Step 5: Gently push down on the

replacement lamp until it is seated in

place.


Note:

Step 6: Re-align the housing into the grooves

of the luminaire.

Step 7: Align the knob with the hole, and

tighten the lamp housing knob.





WARNING: Allow the lamp housing to cool before replacing the lamp.



<u>CAUTION:</u> RISK OF FIRE - Use an MR16 lamp rated at 50 Watts or less.



CAUTION: DRY LOCATIONS ONLY.



It is recommended to use an MR16 lamp with a nominal beam angle of 38 degrees.

Cleaning the Glass Lens



WARNING:

Do not use ammonia-based or other harsh commercial cleaners. Clean lens only as directed.

Commercially available glass cleaning agents should be avoided as they may contain ammonia, other harsh chemical detergents, or abrasive agents. These cleaners may damage the glass surface and the Anti-Reflective coatings. Do not immerse or soak the glass in any cleaning solution.

- Step 1: Remove the beam focus knob from the barrel.
- Step 2: Remove the lens tube from the barrel.
- Step 3: Remove dust with a blast of oil-free air or wipe with a clean, lint-free cloth. Isopropyl alcohol, distilled water, or a 50%-50% mixture of each can be used to clean the glass surface.
- Step 4: Slide the lens tube back into the barrel with the colour frame retainer clip on the top.
- Step 5: Reinstall the beam focus knob.



Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736 London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000 Rome, IT ■ Via Pieve Torina, 48, 00156 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +44 (0)20 8752 8486 Holzkirchen, Det ■ Ohmstrasses 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00 Hong Kong ■ Rn 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuel Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 Service: (Americas) service@elcconnect.com ■ (Det) techserv-hoki@etcconnect.com ■ (Asia) service@elccurope.com ■ (Det) techserv-hoki@etccurope.com ■ (Det) techserv-hoki@etcconnect.com ■ (Det) techserv-hoki@etccurope.com ■ (Det) techserv-hoki@etccurope.c